The BL QUICK-CHANGE Model QCP-100 is an automatic tool changer used in press handling applications for switching part-adsorption end-effectors. It is easy to set up ID confirmation on the Tool plate side, and the block itself is equipped with a protective cover. An electrical signal contact block without a connector on the tool side is available as an option.

## Body designed specially for press applications

Both sides of the Tool plate are cut, which allows it to be placed in an upright position, requiring less space for hand installation.

## Utilities specially considered for press applications


Eight pneumatic vacuum ports are included on standard equipment, and the QCP-100 can be optionally equipped with up to 16 ports. The Tool plate has an optional electrical signal block contact without a connector (R16A/B). Directly-soldered hard-wiring makes a plug unnecessary, so it cannot be damaged when hands are exchanged. It is easy to assign ID discrimination in the hard-wiring section, and the block itself is protected by a metal cover.

### Capability to assign power signals to the lock/unlock sensor from the electrical signal contact block

Two types of power signals may be assigned to the lock/unlock sensor (optional) from the electrical signal contact block.

### Superior fail-safe locking mechanism

BL's unique lock/unlock mechanism contains a mechanical fail-safe feature which does not allow the Master plate and Tool plate to uncouple if the air pressure is shut







Master plate Attachments

(QCP-100A-T-J16A-XXXB)

•6 bolts (M8×55)

\*Seal plate, O-ring and screws

Main Body			
Load capacity (rated load)		980N (100kg)	
Positional repeatability %1		±0.015mm	
Allowable	Bending direction (Tx, Ty)	1,372N·m (140kgf·m)	
dynamic moment	Twisting direction (Tz)	1,372N·m (140kgf·m)	
Coupling force (with air pressure of 0.49Mpa) *2		10,290N (1,050kgf)	
Materials	Frame	Aluminum alloy	
	Lock/ unlock mechanism	Stainless steel	
Overall dimension (when coupled)		φ179×H79.5mm	
Weight	Master plate	3.5kg	
(Main body)	Tool plate	2.0kg	
Self-separating mechanism		Ba <b>ll-l</b> ocking mechanism	
Required air pressure		0.39~0.68MPa (4~7kgf/cm <sup>2</sup> )	
Allowable temperature and humidity ranges		0~50°C、35~90% (Non-condensing)	
Utilities	Pneumatic ports	Rc3/8×8	

V <sub>I</sub>	אנוטווג		
	J16A. J16B	Electrical signals	5A×16 %3 %7
M10	M10A. M10B	Electrical signals	13A×10 %3 %8
L16A		Electrical signals	5A×16 + lock/unlock signals ×3 (Master side only) ※3 ※4 ※7
L07A R16A. R16B R15NA	Electrical signals	13A×7 + lock/unlock signals ×3 (Master side only) ※3 ※5 ※8	
	Electrical signals	5A×16 (Tool side only. An electrical signal contact block without a connector specification) #5 #6	
Uŧi	B15NA B15NB B15PA B15PB	Electric signals Max.50mA DC24V Non-contact system (Please refer to page 41 for details.)	50mA×15 WEB series connector ※3 In Zone 1 IP67
	B15DA B15DB	Electric signals Max.5mA DC12V Non-contact system (Please refer to page 41 for details.)	5mA×15 WEB series connector ※3 IP67
	P38A. P38B	Pneumatic ports	Rc3/8×4
Loc	k/unlock sensor		Two built-in proximity switches

Master plate QCP-100A - M-

(Option A)		
	XXXA	No option
	J16A	Electrical signals 5/

(Option 71)			
		_	
ХХ	XΑ	No option	
J1	J16A Electrical signals 5A×16*3 *7 *9		
M	10A	Electrical signals 13A×10*3*8	
L1	6A	Electrical signals 5A×6 (Three separately assigned lock/unlock signals) #3 #4 #7 #10	
L0	7A	Electrical signals 13A×7 (Three separately assigned lock/unlock signals) #3 #5 #8 #11	
B1	5NA	Non-contact electric signal block Master side NPN output	
B1	5PA	Non-contact electric signal block Master side PNP output	
Р3	8A	Pneumatic ports Rc3/8×4	

(Option B)

XB	No option
ΛD	No option
6B	Electrical signals 5A×16*3*7*12
10B	Electrical signals 13A×10 <sup>±3</sup> <sup>±8</sup>
5NB	Non-contact electric signal block Master side NPN output
5PB	Non-contact electric signal block Master side PNP output
8B	Pneumatic ports Rc3/8×4

### (lock unlock sensor)


SX	No lock/unlock sensor
SA	Lock/unlock sensor A-Type (Customer processes the adaptor plate)
SB	Lock/unlock sensor B-Type (BL Autotec processes the adaptor plate)

### Tool plate QCP-100A

<b>A</b> - T -	(Option A)	
	XXXA	No option
	J16A	Electrical signals 5A×16 <sup>®3</sup>
	R16A	Electrical signals 5A×16 <sup>869</sup> (without a connector)
	M10A	Electrical signals 13A×10*3*
	B15DA	Non-contact electric signal block Too
	P38A	Pneumatic ports Rc3/8×4

# (Option B)

	XXXB	No option	
	J16B	Electrical signals 5A×16*3*7	
	R16B	Electrical signals 5A×16*6*7 (without a connector)	
13	M10B	Electrical signals 13A×10*3*8	
ide	B15DB	Non-contact electric signal block Tool side	
	P38B	Pneumatic ports Rc3/8×4	



## ■Electrical signal contact block



# J16A,J16B

5A×16 (J16A•B) \*3 \*7

Use JMR2116M-D (DDK) for the J16A Master side Use JMR2116F-D (DDK) for the J16A Tool side Use JMR2116MX-D (DDK) for the J16B Master side
Use JMR2116FX-D (DDK) for the J16B Tool side
Use JMR2119M-D (DDK) for the J16A Master side



### M10A,M10B,L07A 13A×10 (M10A·B)\*3\*8

Use D/MS3102A18-1P for the M10A and L07A Master sid Use D/MS3102A18-1S for the M10B Tool side Use D/MS3102A18-19P for the M10B Master side
Use D/MS3102A18-19P for the M10B Master side
Use D/MS3102A18-19S for the M10B Tool side
(Use RoHS-compliant MS receptacle products)



13A×7+lock/unlock signals (L07A)\*\*3 \*\*5 \*\*8





# R16A,R16B (Tool side only

5A×16 (without a connector) \*6 \*7

Please solder the hard-wiring (Please use J16A, J16B or L16A for the Master side)





### B15NA/B,B15PA/B (Master side only) B15DA/B (Tool side only

B15NA/B NPN output B15PA/B PNP output

Receptacle connector: WEBR-2119S-D for B15NA/B and B15PA/B Receptacle connector: WEBR-2116FS-D for B15DA/B

■Lock/unlock sensor



### P38A,P38B

Rc3/8×4



### SA,SB

Two built-in proximity switches verify piston sition on and lock/unlock status

Please contact us for detailed information on the options.

\*\*1 Positional repeatability means the accuracy of position between the one master plate and the one tool plate(A) repeat coupled and uncoupled. It is not possible to apply this positional repeatability to different tool plate(B). \*\*2 Coupling force is the force to achieve specified repeatability. Coupling will be maintained until unlock pressure is applied or the device is damaged. \*3 Plug connector is not included. Please prepare plug connector by customer. For connector, please see correspondence table on page 46. Please use 5A × 16 electrical signal contacts (J16A or R16A) on the tool side. \*4 Please use 13A × 10 electrical signal contacts (MS conecctor (Three of the 10 contacts are not useable) #6 Please use 5A × 16 electrical signal contacts (J16A or R16A) on the master side. \*7 Allowable current is total 30.4A for connector. \*8 Allowable current is total 57.2A for connector. \*9 Please select J16A or R16A for the tool side. \*10 Lock/unlock Sensor SA or SA may be selected for L16A. The receptacle connector is type JMR2119F (19 pins). Please select contact block J16A or R16A for the tool side. \*11 Lock/unlock Sensor SA or SA may be selected for L16A. The receptacle connector is type JMR2119F (19 pins). The receptacle connector is D/MS3102A-1P (10 pins). Please select contact block M10A for the tool side. #12 Please select electric signal contact block J16B or R16B for the tool side. #3 Up to seven electric signals may be used wher L07A is selected for the master side.

ZEUS GIGA

1kg 5kg

10kg 20kg 40kg 60kg

70kg 150kg 220kg 300kg

100kg

300kg

Wire-Saving module / Contact Block Non-contact electric signal block A mechanical safety valve prevents Tod plate drops

Please contact us about compatibility with customized models QC-100 and QC-100A.